SDB HD9-RGB Wireless headphone






T: 0031-(0)85 732 68 59 | E: info@silentdiscobox.com Office: De Hanze 14 6049 HZ Herten (Netherlands) Warehouse: De Hanze 14 6049HZ Herten (Netherlands)

www.silentdiscobox.com

SDB HD9-RGB Wireless headphone



Charge for at least 3 hours for 8 hours of use



T: 0031-(0)85 732 68 59 | E: info@silentdiscobox.com

Office: De Hanze 14 6049 HZ Herten (Netherlands) Warehouse:
De Hanze 14 6049HZ Herten (Netherlands)

www.silentdiscobox.com

SDB HD9-RGB Wireless headphone

The SILENT DISCO BOX HD9-RGB wireless headphone is specially developed for intensive use for silent entertainment. The structural virtue and straightforward controls are clear characteristics of a specified design. The headphone has three pre-programmed RF channels, which are easy recalled with the control switch. For each RF channel, the LED lights up in a different color in the ear pads. Besides the RF channel selection, the headphone is equipped with a volume control and a power switch. Each headphone operates on an internal battery for about 8 hours. Charging the internal battery only takes 3 hours. The adjustable headband makes a tight but comfortable fit, which makes the headphone wearable for children from eight years old and up.

Quick Start.

- 1. Switch the power switch on. The ear pads will illuminate blue, red or green.
- 2. If the ear pads do not illuminate charge the internal battery by plugging the charger next to the power switch. The ear pads will illuminate red. When the battery is fully charged, the ear pad will illuminate green.
- 3. Check the channel switch and make sure that the switch on the transmitter is in the same position. The ear pads on the headphone will illuminate in different color for channel. Blue (channel 1), Red (channel 2), Green (channel 3).
- 4. Adjust the volume control to the desired level.

Technical Features.

The wireless headphone is equipped with a Phase Lock Loop (PLL) an Micro Computer (MCU) system, providing the ultimate frequency stability.

With the Active Noise Reduction Technology the background "hissing" noise (that sometimes occurs during a silent break) is virtually eliminated.

If no signal is received by the headphone, it will immediately mute at once, to save the battery.

Specifications.

Wireless Stereo Headphone with 40mm Mylar speakers.

UHF/RF system working on FM modulation.

Three color LED indicator in ear pads of the headphone which displays the channel.

Frequencies; 863.100Mhz, 863.800Mhz, 864.950Mhz.

Independent volume control.

Frequency response 30 – 20000Hz.

Internal power supplied that will provide an 8-hour operating time.

Signal to noise ratio >75dB.

Channel separation >35dB.

THD <1%



T: T: 0031-(0)85 732 68 59 | E: info@silentdiscobox.com

Office: De Hanze 14 6049 HZ Herten (Netherlands) Warehouse:
De Hanze 14 6049HZ Herten (Netherlands)

www.silentdiscobox.com